



# Grey Water Series NF500GW Treatment System

System Specifications & Installation Instructions



# GREY WATER SERIES NF500GW TREATMENT SYSTEM

## System Specification & Installation Instructions

*New Zealand's Leaders in Eco-Sustainable, Odourless Wastewater and Sewage Systems*

### Compliance Requirements

All NaturalFlow Treatment Systems meet the requirements of the NZ Building Code G13-VM4.

Section 9 of AS/NZS 1546.1:2008 state that tanks constructed to these Standards will meet the requirements of the Code for Clauses B1 and B2, structure and durability.

Compliance with Section 9 of AS/NZS 1546.1:2008 and also Clauses G13.3.4 relating to on-site treatment and disposal systems and G14.3.1 and 14.3.2 relating to the control of foul water as an industrial waste are covered in the 'NaturalFlow Compliance Requirements' document.

Please feel free to ask for a copy of this complete document, if required.

### The Treatment Process

The NaturalFlow Grey Water NF500GW Treatment System comprises of two 0.83m diameter by 1.1m high treatment module and a Dose Chamber module.

The grey water (which includes water from showers, baths, laundry sink, dishwasher, washing machine and hand basins), is separated at its source from the black water (from toilets and kitchen sink), and flows first into the initial treatment chamber, that retains the bulk of the scum and solids; passes through an aerating matrix filter and then into the dose chamber.

This Grey Water NF500GW Treatment module has a buffering capacity of 1000ltrs to contain any surge flows that may be initiated.

The size and extent of the disposal systems are determined by the receiving environment and the expected flow volumes. Factors such as soil types, slope and the proximity of potentially sensitive environments and constraints such as creeks, bores, wells etc determine the extent, location and type of disposal system chosen. The DC500 chambers have a reserve capacity of 1000ltrs where pump loading is necessary to allow for 24hrs emergency storage should a pump fail. The Grey Water NF500GW Treatment System is capable of treating 1000ltrs per day of grey water.

### Grey Water Module & Dose Chamber Specifications

Tanks are made of Cotene 9050 which is a linear medium density polyethylene, designed specifically for rotational moulding of large tanks and products that require a high level of rigidity. It contains a fully formulated long term UV stabilization package (with a minimum UV8 rating) and is suitable material for wastewater treatment containment meeting all the requirements of Section 4.3.3 of AS/NZS 1547:2012 which cross references the structural performance requirements of its section 2.4.2.3 back to the relevant provisions of AS/NZS 1546.1, which for plastic septic tanks constructed via by rotational moulding using thermoplastics (polyethylene) are set out in Section 9 of that Standard. These tanks have an expected lifespan of 50 years.

*See our website: [www.naturalflow.co.nz](http://www.naturalflow.co.nz)*

# GREY WATER SERIES NF500GW TREATMENT SYSTEM

## System Specification & Installation Instructions

*New Zealand's Leaders in Eco-Sustainable, Odourless Wastewater and Sewage Systems*

### **Grey Water Module**

500ltrs Nominal capacity  
830mm Diameter  
1100 mm O/A height

### **Dose Chamber**

500ltrs Nominal capacity  
830mm Diameter over main body  
1100mm O/A height

### **Installation Location and Certification**

These tanks are not designed for vehicle loads and shall be located no closer than 1.50m to a driveway, road frontage or a building. If for any reason the tank is located where vehicle traffic may drive over the tank or approach closer than 1.50m, or where it may be trampled on by farm stock then the tank should be protected by a concrete slab designed to support these loads. Surface water must also be diverted from flowing into the installation.

Installation must be certified to AS/NZS 1547:2012, the certificate to be issued and held by the regulatory authority.

### **High Water Table Installations**

All tanks have been engineered and designed with support ribbing for maximum strength, in accordance with the NZC 3604. Clauses B1 and B2 for structure and durability, to withstand any hydraulic pressures, both lateral and uplift, created by high water table conditions, even when the tanks are completely empty at install stage.

As per the NaturalFlow Systems installation instructions, in these conditions, tanks must be anchored in with concrete around base, as per the installation instructions, to height as specified.

### **Plumbing Pipes and Fittings**

All internal plumbing is done with PVC pipes with appropriate connections according to AS/NZS 1260 and AS/NZS 4130.

### **Backfill and Bedding**

Place and bed to NZBC G13/AS2, using compacted granular metal, in layers not exceeding 100mm.

### **Electrical**

Where a pump is required on a flat site electrical connection must be installed according to AS/NZS 3000 and the control and alarm system must be in a weatherproof housing located in a readily visible position.

***If in doubt contact the experts on 0800 628 356 or [sales@waterflow.co.nz](mailto:sales@waterflow.co.nz)***

# GREY WATER SERIES NF500GW TREATMENT SYSTEM

## System Specification & Installation Instructions

*Zealand's Leaders in Eco-Sustainable, Odourless Wastewater and Sewage Systems*


### Warranty

WATERFLOW NZ LTD warrants that the NaturalFlow System will be free from defects in material and workmanship for the following periods of time from the date of installation as set out in the following conditions:

1. Roto-Molded tanks 15yrs
2. Filter media 15yrs
3. Dosing float/and or pumps 2yrs
4. WATERFLOW NZ LTD will at its discretion replace or repair such components that prove to be faulty with the same or equivalent part at no charge.
5. Warranty of operation covers the performance of the NaturalFlow systems as connected to the effluent inflow for which they are designed, and also installed to the criteria as set out in the relative installation instructions and procedures.

Warranty excludes defects due to:

- A) Failure to use the system in accordance with owner's manual.
- B) A force majeure event outside the reasonable control of WATERFLOW NZ LTD such as (but not limited to) earthquake, fire, flood soil subsidence ground water table variations or plumbing fault.
- C) Modifications to surrounding landscape contours after installation
- D) The actions of a third party
- E) The system required to bear loads (either hydraulic or biological) greater than that for which it was designed
- F) Any modifications or repairs undertaken without the consent of WATERFLOW NZ LTD
- G) Failure, where applicable, to fence and plant land application system (disposal field)



1st June 2014  
Dean Hoyle  
Managing Director

# GREY WATER SERIES NF500GW TREATMENT SYSTEM

## System Specification & Installation Instructions

### *NaturalFlow Series NF1500 Dose Installation Instructions*

#### **Gravity Dose System Install**

The NaturalFlow system is to be installed or signed off by a registered Drain layer to the design specified by Waterflow NZ Ltd.

The following installation instructions and procedures followed correctly will ensure System performance is not compromised in any way.

1. Excavate a 1.4m (wide) x 2m (long) level platform for the Grey Water Modules at the appropriate depth, so when it is placed there is adequate fall to inlet from its source.
2. Lay 100mm of bedding metal on platforms and place Grey Water Module then Dose Chamber.
3. Fit the short length of DWV50 supplied, in outlet hole, in base of Grey Water Module
4. Apply some lubrication to the UNISEAL<sup>®</sup> and carefully connect Grey Water Module and Dose Chamber with DWV50, fitted to Wormerator<sup>®</sup>. (see UNISEAL<sup>®</sup> instructions appendix B) N.B. pipe to protrude 50mm through UNISEAL<sup>®</sup>
5. Where possible excavate a trench away from System and lay drain coil and drainage metal at the base of the system to drain away any surface or ground water. On a flat or high water table site System must be bedded in as per appendix A below
6. Trench from Dose Chamber outlet to disposal field, ensuring there is a constant fall from outlet to disposal field
7. Connect Grey Water from source to Module
8. Take a minimum of 2 photos at this point to show correct installation for sign off.
9. Back fill around tanks with pea metal. DO NOT back fill with soil or clay of any type as this can cause point pressure on the modules and could cause distortion.

**Caution:** System must be protected from excessive super imposed loads both lateral and top loads. E.g. loads from vehicular traffic. There needs to be at least 2m of clearance maintained around system.

# GREY WATER SERIES NF500GW TREATMENT SYSTEM

## System Specification & Installation Instructions

### *NaturalFlow Series NF1500 Pump Installation Instructions*

#### **Pump Dose System**

The NaturalFlow system is to be installed or signed off by a registered Drain layer to the design specified by Waterflow NZ Ltd.

The following installation instructions and procedures followed correctly will ensure System performance is not compromised in any way.

1. Excavate a 1.4m (wide) x 2m (long) level platform for Grey Water Modules at the appropriate depth, so when it is placed there is adequate fall to inlet from its source.
2. Lay 100mm of bedding metal on platforms and place Grey Water Module then Dose Chamber.
3. Fit the short length of DWV50 supplied, in outlet hole, in base of Grey Water Module
4. Apply some lubrication to the UNISEAL<sup>®</sup> and carefully connect Grey Water Module and Dose Chamber with DWV50, fitted to Wormerator<sup>®</sup>. (see UNISEAL<sup>®</sup> instructions appendix B) N.B. pipe to protrude 50mm through UNISEAL<sup>®</sup>
5. Where possible excavate a trench away from System and lay drain coil and drainage metal at the base of the system to drain away any surface or ground water. On a flat or high water table site System must be bedded in as per appendix A below
6. Connect Grey Water from source to Dose Chamber
7. Take a minimum of 2 photos at this point to show correct installation.
8. Back fill around tanks with pea metal. DO NOT back fill with soil or clay of any type as this can cause point pressure on the modules and could cause distortion.
9. Connect pump with fittings supplied and lay feed line to disposal field.

**Caution:** System must be protected from excessive super imposed loads both lateral and top loads. E.g. loads from vehicular traffic. There needs to be at least 2m of clearance maintained around system.

# GREY WATER SERIES NF500GW TREATMENT SYSTEM

## System Specification & Installation Instructions

### Appendix A and B

#### Appendix A


**High Water Table:** For installation in high water table areas, make sure you have a pump to pump away ground water whilst installing. Excavate a pump cavity to one side of the platform and pump ground water away during entire installation process. Half fill dose tank with water, this will flow back into Wormerator as well and will help with resisting the hydraulic uplift (ensure that Wormerator is not completely flooded). Either lay 2-3m<sup>3</sup> of concrete around the base of the tanks or mix 3 bags of cement/cube of GAP20 (or similar) metal to form a mass to stop any hydraulic uplift. Leave water in tanks for at least 12 hours after installation is completed and then pump out to allow Wormerator to dry out.

#### Appendix B

Instructions for fitting UNISEAL®

1. Cut hole to the Hole saw size indicated for the UNISEAL® you are using. Either 127mm hole for a 4"/100mm pipe or 67.2mm hole for a 2"/50mm pipe.
2. Ensure that the hole is clean cut with sharp edges. Irregularities could cause poor seating and ultimate leakage.
3. Insert the UNISEAL® into the hole with the wide side facing the pipe to be inserted.
4. Make certain that the pipe end to be inserted is clean cut. File the edges so that there are no sharp points to cut UNISEAL®.
5. Using Detergent, lubricate the outside of the pipe end to be inserted, then push the pipe through the UNISEAL® from the large flange side. The detergent will be squeezed off as the pipe passes through the UNISEAL®. The co-efficient of friction of the rubber holds the pipe tightly in place.


Side Elevation:



# GREY WATER SERIES NF500GW TREATMENT SYSTEM

## System Specification & Installation Instructions

### NaturalFlow Series NF500GW Flow Charts







**naturalflow**

eco-wastewater & sewage systems  
by Waterflow NZ Ltd

**"We do it simpler"**



**Call us today to discuss your needs**

**0800 628 356**

**Or for more information [www.naturalflow.co.nz](http://www.naturalflow.co.nz)**



Head Office  
Waterflow NZ Ltd  
PO Box 24, 1160 State Highway 12,  
Maungaturoto 0547, New Zealand  
P. 09 431 0042  
E. [sales@waterflow.co.nz](mailto:sales@waterflow.co.nz)

South Island Office  
NaturalFlow South Ltd,  
15B Wilkinsons Road,  
Harewood, Christchurch 8051  
P. 03 323 8541  
E. [sales@naturalflowsouth.co.nz](mailto:sales@naturalflowsouth.co.nz)

[www.naturalflow.co.nz](http://www.naturalflow.co.nz)